



Yealink® SIP-T57W Phone

The Yealink® SIP-T57W is a 27-line, touch screen, Gigabit phone packed with many advanced features that will enhance your day-to-day business activities and make your life easier. This guide is designed to help you use some of the most popular features with your new Yealink® SIP-T57W phone.

Soft Keys

The soft keys located on the touch screen perform the functions that appear below the icon. Their functions are context sensitive, which means the function of the soft keys change depending upon your current activity. For example, when conferencing, the soft keys display functions related to conferencing.

Line Keys

With the SIP-T57W, you can access up to 27 touch screen virtual keys. The line keys, located on the left and right of the display screen, indicate the status of your lines and associated activity. The icons inform you when a line is idle, ringing, in use or on hold. If you have more than 11 shared lines or BLFs assigned, touch the bottom right More line key to show the additional key assignments.

Navigation Keys

Navigation is performed by touching any on-screen icon, then using your finger to scroll up or down through any lists. To select an item, touch any entry in the list or touch an icon.

Answer a Call

To answer a call, simply pick up the handset or press the Answer soft key, Speakerphone key or Headset key.

Place a Call

To place a call, simply pick up the handset or press the Speakerphone key or Headset key, then dial the number. Calls can be placed by choosing a number from History or the Directory.

- *72 Call Forwarding Always Activation
- *73 Call Forwarding Always Deactivation
- *90 Call Forwarding Busy Activation
- *91 Call Forwarding Busy Deactivation
- *92 Call Forwarding No Answer Activation
- *93 Call Forwarding No Answer Deactivation
- *44 Call Recording (if enabled)
- *67 Calling Line ID Delivery Blocking per Call
- *65 Calling Line ID Delivery per Call
- *68 Call Park
- *88 Call Park Retrieve
- *98 Call Pickup
- *11 Call Retrieve
- *69 Call Return
- *70 Cancel Call Waiting
- *99 Clear Voice Message Waiting Indicator
- *55 Direct Voicemail Transfer
- *78 Do Not Disturb Activation
- *79 Do Not Disturb Deactivation
- *62 Voice Portal Access
- *66 Last Number Redial

Note: Some of these codes may not be available to all users. See your group admin to add features.

Other Features

Set up Voicemail

- If calling, dial *62 or your extension.
- At the prompt, enter in a unique passcode, then press #.
- Re-enter your passcode, then press #.
- Follow instructions to record your name.
- Follow prompts to:
 - Access voice mailbox
 - Access greetings menu
 - Change passcode
 - Exit voice portal

Retrieve Voicemail Messages

A blinking red “message waiting” indicator light notifies you when you have a new voicemail message.

- To check your voicemail, press the Messages key.
- To use Visual Voicemail:
 - Touch the entry for your extension from the list.
 - Touch the screen and drag your finger up or down through the list of voicemails, then touch the message you want to play.
 - Touch Delete to delete the message.
 - Touch Option to view details or place a call back.
- To call voicemail, call *62 or your extension and do the following:
 - Enter your voicemail passcode if prompted, then press #. (If you forgot your passcode, please contact your system administrator.)
 - Follow the audio prompts.

Hold and Resume a Call

- To hold, press the Hold soft key or Hold hard key.
- To resume, press the Resume soft key or press the Hold hard key again.
- To dial a number, scroll to the desired entry, then touch the entry.
- To disable, follow the same steps and touch the Off soft key.

Access Call Lists

- Call History can be accessed touching the History soft key.
- On the left, touch whether to view Network Calls or the subset of Placed Calls, Missed Calls or Received Calls.
- To view information about the call, touch the “i” icon to the right of the entry.
- To dial a number, scroll to the desired entry, then touch the entry.

Do Not Disturb

- To enable Do Not Disturb, press the DND soft key.
- To disable, press the DND soft key again.

Make a Three-way Call

After the first call is connected:

- Touch the Conference softkey. The active call will be placed on hold.
- Dial the new party and touch Conference on the right.
- When the call connects, touch the Conference soft key again to join the calls.

Transfer a Call

After the first call is connected:

- Press the Transfer hard key or soft key. (The active call will be placed on hold.)
- To transfer the call unannounced, enter the number and press the B Transfer soft key.
- To speak to the transfer-to party first, dial the number or extension and press Call.
- When the party answers, announce the transfer. Then press Transfer again to complete or hang up. If a Blind transfer, the call will transfer automatically.

To transfer the call directly to another user’s voicemail:

- During the transfer process, dial *55 instead of the extension.
- Dial the extension, followed by #.
- A confirmation will announce the transfer is complete.

Other Features (continued)

Call Forwarding

- Touch the Menu soft key.
- Touch the Features icon.
- Touch Call Control.
- In the right-hand list, use your finger to scroll to the feature Call Forward feature and touch the entry.
- Choose from Always Forward, Busy Forward or No Answer Forward touch that entry.
- Use the touch screen to enable options by touching the On radio button.
- Touch each field and enter information, such as the Forward to number using the on-screen keyboard, then touch the enter soft key on the right-hand side of the on-screen keyboard to complete your entry.
- Touch the Save soft key to enable the forwarding option.
- To disable, follow the same steps and touch the Off radio button to toggle the call forward option off, then touch the Save soft key to change your forwarding setting.

Shortcuts

- Pick up handset and dial:
 - *72 = Call Forwarding Always
 - *90 = Call Forwarding Busy
 - *92 = Call Forwarding No AnswerEnter destination number, then press #.
- To deactivate, dial:
 - *73 = Call Forwarding Always
 - *91 = Call Forwarding Busy
 - *93 = Call Forwarding No Answer